





## SG070CG01 Little Wonder



### SG070CG01

KEY No. DESCRIPTION

KEY No. DESCRIPTION

	1	SG35085A	Switch
	2	SG35313A	Holder, Fuse
	3	SG35312A	Fuse 3AG - 35A






	4	SG35083A	Flex. Cable Assy
	5	SG36704A	Replacement Core
	6	SG37451A	Rep. Core End & Bearing

## Flexible Downtubes

		SG050BG02	Flexible Drive Assy – SGV / Super Pro, Multishear, Handishear & Ultra Pro
		SG050BG01	Flexible Drive Assy – 3-Speed
		SG051BH01	Flexible Drive Assy – Shear Power, Shaft, X508, EV
		SG29397 A	Flexible Drive Assy – Super Combishear
		SG28838 A	Flexible Drive Assy – Super Handishear
		SG049BF01	Flexible Drive Assy – Old Farm Model
		SG42224 A	Flexible Drive Assy – Super Portashear
		SG35083 A	Flexible Drive Assy – Little Wonder
		SG37106 A	Flexible Drive Assy – 3 Speed
		SG29394 A	Inner Core for – SG50, SG51, SG24A, 38A, 97A, BF01
		SG36704 A	Inner Core – Little Wonder
		SG37111 A	Helical Spline Sleeve Assy – For Flexible Drive

SUPERSHEAR

## Downtubes

		SG056BN01	Ultra Pro Downtube and long Core Assy only. Includes short tube
		SG028AF01	Ultra Pro Downtube and long Core Assy. With Short Core Spline Type
		SG027AE01	Ultra Pro Downtube and long Core Assy. With Short Core Pin Type
		SG034AM01	Pin Type – Suit Farm Model